

Link do produktu: <https://sklep.mkservice.pl/da97-15689a-balkonik-gorny-zespolony-z-klapka-assy-guard-dairy-3050-bmf-assy-p-39023.html>



DA97-15689A - Balkonik górny (zespolony z klapką) - ASSY GUARD DAIRY 3050_BMF,ASSY

Cena	154 zł
Dostępność	Na zamówienie
Numer katalogowy	DA97-15689A
Kod producenta	DA97-15689A
Producent	Samsung

Opis produktu

DA97-15689A zastępuje część o kodzie DA97-13477A

UWAGA!

Część dostępna na indywidualne zamówienie konfigurowana pod numery seryjne, importowana dla klienta. Część nie podlega zwrotowi.

Część jest zgodna z dokumentacją serwisową urządzeń:

Kod modelu	Skrót handlowy
RB29FDRNDSA/EF	RB29FDRNDSA
RB29FERNCSA/EF	RB29FERNCSA
RB29FERNCSS/EF	RB29FERNCSS
RB29FERNDSA/EF	RB29FERNDSA
RB29FERNDSS/EF	RB29FERNDSS
RB29FERNDWW/EF	RB29FERNDWW
RB29FSJNDSA/EF	RB29FSJNDSA
RB29FSRNDSA/EF	RB29FSRNDSA
RB29FSRNDSS/EF	RB29FSRNDSS
RB29FSRNDWW/EF	RB29FSRNDWW
RB29FWRNDSA/EF	RB29FWRNDSA
RB29HER2CSA/EF	RB29HER2CSA
RB29HSR2DSA/EF	RB29HSR2DSA
RB29HSR2DWW/EF	RB29HSR2DWW
RB30J3000SA/EF	RB30J3000SA
RB30J3000WW/EF	RB30J3000WW
RB30J3200SS/EF	RB30J3200SS
RB30J3215SS/EF	RB30J3215SS
RB30J3230SA/EF	RB30J3230SA
RB30J3405SS/EF	RB30J3405SS
RB30J3420SS/EF	RB30J3420SS
RB31FDRNDBC/EF	RB31FDRNDBC
RB31FDRNDSA/EF	RB31FDRNDSA
RB31FDRNDSS/EF	RB31FDRNDSS

RB31FERNBSA/EF	RB31FERNBSA
RB31FERNBSS/EF	RB31FERNBSS
RB31FERNCSA/EF	RB31FERNCSA
RB31FERNCSS/EF	RB31FERNCSS
RB31FERNCWW/EF	RB31FERNCWW
RB31FERNDBC/EF	RB31FERNDBC
RB31FERNDEF/EF	RB31FERNDEF
RB31FERNDSA/EF	RB31FERNDSA
RB31FERNDSS/EF	RB31FERNDSS
RB31FERNDWW/EF	RB31FERNDWW
RB31FSRNSA/EF	RB31FSRNSA
RB31FSRNDSS/EF	RB31FSRNDSS
RB31FSRNDWW/EF	RB31FSRNDWW
RB31HER2BSA/EF	RB31HER2BSA
RB31HER2CSA/EF	RB31HER2CSA
RB31HSR2DSA/EF	RB31HSR2DSA
RB31HSR2DWW/EF	RB31HSR2DWW
RB33J3030SA/EF	RB33J3030SA
RB33J3200SA/EF	RB33J3200SA
RB33J3200WW/EF	RB33J3200WW
RB33J3205SA/EF	RB33J3205SA
RB33J3215SS/EF	RB33J3215SS
RB33J3219SS/EF	RB33J3219SS
RB33J3230BC/EF	RB33J3230BC
RB33J3230WW/EF	RB33J3230WW
RB33J3315SA/EF	RB33JFEJNSA
RB33J3415SS/EF	RB33J3415SS
RB33J3419SS/EF	RB33J3419SS
RB33J3420SS/EF	RB33J3420SS
RB33J3420WW/EF	RB33J3420WW
RB33N300NSA/EF	RB33N300NSA
RB33N301NSA/EF	RB33N301NSA
RB33N340MSA/EF	RB33N340MSA
RB33N340NSA/EF	RB33N340NSA
RB33N341MSA/EF	RB33N341MSA
RB33N341MSS/EF	RB33N341MSS
RB33N341MWW/EF	RB33N341MWW
RB33N341NSA/EF	RB33N341NSA
RB34N5000SA/EF	RB34N5000SA
RB34N5200SA/EF	RB34N5200SA
RB34N5400SS/EF	RB34N5400SS
RB34N5491SA/EF	RB34N5491SA
RB37J5000EF/EF	RB37J5000EF
RB37J5000SA/EF	RB37J5000SA
RB37J5005B1/EF	RB37J5005B
RB37J500MSA/EF	RB37J500MSA
RB37J5010SA/EF	RB37J5010SA
RB37J5010WW/EF	RB37J5010WW
RB37J5015SS/EF	RB37J5015SS
RB37J501MSA/EF	RB37J501MSA

RB37J501MWW/EF	RB37J501MWW
RB37J5029SS/EF	RB37J5029SS
RB37J506MSA/EF	RB37J506MSA
RB37J5110SA/EF	RB37J5110SA
RB37J5120SS/EF	RB37J5120SS
RB37J5220SA/EF	RB37J5220SA
RB37J5220WW/EF	RB37J5220WW
RB37J5225SS/EF	RB37J5225SS
RB37J5235SS/EF	RB37J5235SS
RB37J5235WW/EF	RB37J5235WW
RB37J5249SS/EF	RB37J5249SS
RB37J5315EF/EF	RB37J5315EF
RB37J5315SS/EF	RB37J5315SS
RB37J5320SS/EF	RB37J5320SS
RB37J5325SS/EF	RB37J5325SS
RB37J5325WW/EF	RB37J5325WW
RB37J5329SS/EF	RB37J5329SS
RB37J5345SL/EF	RB37J5345SL
RB37J5345SS/EF	RB37J5345SS
RB37J5900SL/EF	RB37J5900SL